

The new FWM TS – 7 day programmable touch screen thermostat




This stat keeps you well ahead of competitors allowing you to offer a state of the art 16amp programmable thermostat that has 6 daily settings and can be used as a floor, air or air & floor combined unit!





What's more this thermostat is easy to program, for 7-day use of the thermostat follow these simple instructions.











You can set 6 periods of heating time each day and these are called events, each event can have a different temperature. This control is designed specifically to control under floor heating.

Important: This stat is set up to monitor the air temperature so before you start to program the stat you need to change it to a floor-sensing thermostat. Also you may want to adjust the programmer to work on a 5-2 day schedule, 6-1 or 7 day. To do all this, go to advanced settings.


When the stat is turned off press the on/off button and the  (Menu) button at the same time. This will give you advanced settings and 1ADJ should show. Press  again and 2SEN should show. Press the arrow  button until it says "OUT" on the screen. The floor sensor is now activated.












Press  4 more times and 6PRG will show. Now you can adjust the programme schedule with the  button. If this is set to "off" the programmer cannot be used. Press the on/off button to come out. Now turn the thermostat on.

Setting the day & Time

- Press and hold the clock  key until the minutes start to flash. Use the arrows  to increase or decrease. Once set press the  key
- Now the hours should be flashing, use the up  and  down keys to enter the correct hour, when correct press the  key again and the small number to the left of the screen should be flashing (1-Monday, 7-Sunday) Repeat the process pressing the up  and  down arrows to set the correct day. 
- When the time and day has been set press the  button again.
- You have now set the day & time.
-

To program the time the heating comes on & turns off.

Hold the  key for 5 seconds until the days of the week are showing on the screen.

- Set event 1, (sun symbol) by using the arrow keys to alter the time as before and set the time you want the heating to come on (set an hour before you plan to use the floor). Now press 
- Now set the temp you want the tiles to be (25-28⁰c) & press 
- Now set the time you want the heating turned off & press 
- Now set the off temperature (11-15⁰c) & press 
- Now set the time you want the heating on for lunch & press 
- Now set the temp you want the tiles to be (25-28⁰c) & press 
- Now set the time you want the heating turned off & press 
- Now set the off temperature (11-15⁰c) & press set
- Now set the time you want the heating on for the evening & press 
- Now set the temp you want the tiles to be (25-28⁰c) & press 
- Now set the time you want the heating turned off & press 
- Now set the off temperature for the night (11-15⁰c) & press 

N.B. If you have the programmer set at a 5-2 or 6-1 day schedule you will set different times for the weekend.

Once you are happy with the settings press on/off to return. To activate the timer you must have the ⌚ symbol showing above the current temperature on the display.

Turning the thermostat on or off

- Press the on/off key to switch the thermostat on or off.
- The time and the set temperature will show simultaneously at the bottom of the screen and the current temperature will show above it.

Key-lock function

Press both the up & down arrow keys for 5 seconds to lock or unlock the control.