



- A. Fit the bracket (1) to the wall using wall plugs (2) and screws (3)
- B. Insert pivot (4)
- C. Slide the cover (5) over the bracket (1)
- D. Fit the handset holder (7) to the bracket (1) using screw (8) with spacer (6) between them
Use a hand screwdriver. Over tightening screws can damage these parts.