


Transition bath waste

44400023735



DIMENSIONS:

Width: 70mm

Depth: 70mm

Height: 37mm

IMPORTANT:

All parts should be removed from their packaging and inspected for any transport damage and completeness prior to installation; you should read these instructions throughout before commencing installation.

We do not accept responsibility for problems that may occur through improper installation. Always ensure you have sufficient hot and cold water pressure available to allow correct function before specifying or installing this product.

We strongly recommend installing particle filters and isolation valves to both the hot and cold feed pipes in an accessible position. This will help to prevent premature failure of the valves and ease any future maintenance.


Shut off your water heating system and ensure that your mains stopcock is closed. Ensure both the hot and cold water supplies are isolated before commencing installation.

CARE AND MAINTENANCE:

To maintain the appearance of this product, ensure that it is regularly cleaned only using a clean, soft damp cloth. A solution of warm water and a mild liquid detergent may be used where necessary, and then the fitting rinsed thoroughly and wiped dry. Any other cleaning action or cleaning products will invalidate your warranty.

Abrasive cleaners, scouring cleaners, limescale cleaners and acidic cleaners must not be used under any circumstances. Avoid contact with all solvents (including chlorinated solvents, ketones or acetones as these may result in surface deterioration or etching). Also avoid contact with any harsh household chemicals such as bleach cleaners, drain cleaners, rust removers, paint strippers and toilet bowl cleaners, toothpaste, mouthwash, bar keepers friend or Brasso.

Key	Description	Qty
A	Bath waste	1
B	Upper seal	1
C	Bath	0
D	Lower seal	1
E	Fixing nut	1



1. Place bath waste (A) and upper seal (B) centrally through bath hole (C) as shown. Note orientation of upper seal (B).
2. Pass lower seal (D) over the bottom threaded end of bath waste (A) so that it is flush with bottom of bath (C).
3. Screw fixing nut (E) to bottom threaded end of bath waste (A) securely so that it is flush with bottom of lower seal (D) and bath (C).

Note: If upper or lower bath surfaces are uneven, Silicone sealant may need to be used on seals (B & D).

4. Connect the bath waste (A) to the inlet pipework using the relevant 1 ½" BSP connector.